



(Step 1) Lift the 110 pound Muscle Wall  
Avoid Dropping



(Step 4) Roll out the poly-string plastic  
Plastic-Sheet must be used



(Step 2) Slide wall onto opposing connector



(Step 5) Zip-Tie plastic to each Muscle Wall



(Step 3) Ratchet strap around each connection



(Step 6) Dig a six inch deep trench  
Do NOT pull plastic sheeting tight



(Step 7) Bury the edge of plastic to create seal



(Step 8 A) Loop red-strap around rebar strap



(Step 7 A) Alternative method to trenching is to use 3/8 inch chain to keep plastic in place.



(Step 8 B) Tighten red-strap evenly



(Step 8) If using a corner wall, use red-straps



(step 9) Fill each Wall completely with water