



Step 1

About 1-2 feet away from the toe of the Muscle Wall dig a trench approximately 16 inches deep that spans the entire wall of Muscle Wall.



Step 2

Roll out and unfold the liner over the Muscle Wall, placing about 16-20 inches of the edge of the liner in the trench, and fill the trench back in with soil. Ensure that the liner is pressed down flat against the wall. Compact the soil as much as possible.



Step 3

Optional: Install a liner clip either every wall or every other wall according to personal preference.



Step 4

Secure the liner by cutting a small horizontal slit in the liner and pulling the safety strap through and ratcheting it down. If you installed liner clips, run the strap through the loop in the clip.